

How to prepare a working solution?

In order to obtain selected concentration, measure the appropriate amount of water in a tub or a bucket, then add the amount of disinfectant concentrate given in the table.

Concentration	4 %	2 %	1 %	0,5 %	0,25 %
Concentrate amount (ml)	40	20	10	5	2,5
Water amount (ml)	960	980	990	995	997,5

Concentrate efficiency (liters of solution)

Concentration	Efficiency from 1l of concentrate	Concentration	Efficiency from 1l of concentrate
0,25 %	400 liters	2 %	50 liters
0,5 %	200 liters	3 %	33 liters
1 %	100 liters	4 %	25 liters

How to use a doser?

- 1** Open the cap over the dispenser
- 2** Press the bottle. The liquid flows through the tube to the appropriate level of the dispenser
- 3** Tilt the bottle as shown in the picture and pour the discharged amount of concentrate into the water

